

Kumo Wireless Temperature & Humidity Sensor Setup

Model: PAC-USWHS003-TH-1

This sensor allows remote temperature and humidity sensing for any indoor equipment equipped with Kumo Cloud or Kumo Station. It can also be used to activate a humidifier through Kumo Station.

Prior to sensor installation Kumo Wireless Interface should be installed & functioning from the Kumo Cloud App

Setup from Kumo Cloud App:

1. Tap Settings.
2. Tap System Setup.
3. Tap – Installer Settings.
4. Enter Installer Pin (9999).
5. Tap on the specific zones with existing indoor units you are looking install the wireless sensor with.
6. Tap Advanced.
7. Tap Add Accessory.
8. Tap Add Wireless Sensor.
 - a. The Kumo Cloud App will now search for the closest sensor.
 - i. Before tapping Add Wireless Sensor, remove the tape from sensor to activate.
 - ii. A chirping sound should be heard from the sensor when tape is removed. If not tap the sensor on a hard surface to activate.
 - iii. Watch for the sensor to appear in the app.
9. Tap the sensor you are looking to install once it appears on the app.
10. Select the unit that you would like the sensor paired with.
11. Tap save and the sensor will be added.
12. Repeat for additional sensors.
13. Locate or mount sensor approximately 10' unobstructed from the wireless interface.
 - a. Face the small hole on the sensor into the room space.